



2013 Mac Pro Heat Sink Installation

Please install the included heat sink to ensure the drive runs at the proper temperature.

1. Remove the white plastic backing from the heat sink.
2. Align the heat sink with the similar-sized square chipset at the center of the drive.
3. Press down to affix the heat sink. Only a modest amount of pressure is required.
4. Install the modified drive into the Mac Pro as you normally would.

1



2



If you have questions please contact our customer support team www.owcdigital.com/support/contact