



OWC ROVER PRO

Wheels Kit for 2019 Mac Pro



INCLUDES

- (4) OWC Rover Pro wheels
- (4) Wheel stoppers



Innovative

Patent-pending design



Fast Toolless Install

Hand tightens in
under 2 minutes



Stay in Place

Includes anti-roll
wheel stops

INSTALLATION

Please follow the steps below to install your new casters onto the 2019 Mac Pro. If you encounter any difficulty please contact our award-winning support team. www.owc.com/support/contact

1. Remove the four casters and the four wheel-stop brackets from the foam cutouts.
2. If it is not already, shut down the Mac Pro and disconnect it from the power cable and all external devices. Then, carefully set the Mac Pro on its side, near the edge of a work table so that the four feet are a 2-3 inches clear of the table's edge. Brush away any debris on the bottom of the feet.



3. Take a caster and unscrew the ring portion from the top of the assembly. Set the wheel portion aside for now.



4. Place the caster ring over top of the Mac Pro foot, with the slot facing towards the center of the chassis.



5. Holding the caster ring in place to ensure it doesn't rotate, take the wheel portion from Step 3 and screw it back onto the ring until the caster is secured to the Mac Pro's foot.

TECHNICAL SUPPORT



Phone: M-F, 8am-6pm CT
1.866.692.7100 (N. America)
+1.815.338.4751 (Int'l)



Chat: M-F, 8am-6pm,
Sat. 9am-5pm CT
www.owc.com/support



Email: Answered
within 48 hours
www.owc.com/support



6. Repeat Steps 3-5 for the remaining 3 wheels, then carefully place the Mac Pro onto the floor. To keep the Mac Pro from rolling, you can use the included wheel-stop brackets. Simply place a bracket around the base of each wheel.